

**REGENT** GENAU MEINE UHR.



# Bedienungsanleitung

Werk 8N33/6T33

# MIYOTA

UNIVERSAL MASTERPIECE BORN IN JAPAN

MADE IN JAPAN

METAL MOVEMENT

INSTRUCTION MANUAL FOR MIYOTA WATCH MOVEMENT

CALIBRE NO. 8N33/ 6T33

MANUAL-WINDING & FULL SKELTON MOVEMENT


---

A) DISPLAYS AND BUTTON

B) WINDING THE MAINSPR

C) SETTING THE TIME

A) DISPLAYS AND BUTTON



**B) WINDING THE MAINSPRING**

Manual winding watch can be wound by turning the crown clockwise in Normal position.

Wind several times clockwise. It will start to move naturally.

※ When the mainspring is full-winded (35~39 rotations of the crown are needed), stop turning the crown.  
If not to stop, it can be a cause of trouble.

**C) SETTING THE TIME**

1. Pull the crown out to the 1st Click Position.

2. Turn the crown to set hour and minute hands.

3. After the time has been set, push the crown back to the Normal position.

*These specifications might be changed without prior notice.*

**CITIZEN WATCH CO., LTD.**